

GEANT4 Introductory Course

Instituto de Estudos Avançados – Instituto Tecnológico de Aeronáutica,
São José Dos Campos, Brazil
July 28th – August 1st, 2014

Scoring

Miguel A. Cortés-Giraldo

based on the original lecture by Sebastien Incerti (IN2P3)



Geant 4

➤ What is scoring?

- Three types of scoring:
 - User hooks
 - Sensitive Detectors
 - Command-based scoring

Scoring: Extraction of Useful Information

3

- Given geometry, physics and primary track generation, Geant4 does proper physics simulation “silently” by default.
 - You have to add a bit of code to extract information useful to you
- There are several ways:
 - Use **user hooks** (`G4UserTrackingAction`, `G4UserSteppingAction`, etc.):
 - You have full access to almost all information
 - Straight-forward, but **do-it-yourself**
 - Use **sensitive detectors**:
 - Assign `G4VSensitiveDetector` to a volume and optionally generate “hits”
 - Use **user hooks** (`G4UserEventAction`, `G4UserRunAction`) to get event / run summary
 - **Built-in scoring commands**:
 - Most commonly-used physics quantities are available.
 - (Other less common alternatives)



Geant 4

Outline

4

✓ What is scoring?

➤ **Three types of scoring:**

➤ **User hooks**

- Sensitive Detectors
- Command-based scoring

User Hooks

5



- “Do it yourself” approach
- In Geant4, you have full access to almost all information:
 - G4UserSteppingAction
 - G4UserTrackingAction
 - G4UserEventAction
 - G4UserRunAction
- This is **well adapted to small applications** & Geant4 examples.
- In **large applications**, where many data from many volumes need to be recorded, **this becomes too heavy**:
 - Crowded UserSteppingAction.
 - Need to subdivide problem, which Sensitive Detectors already do for you.

- In your **SteppingAction**, check that particle is in volume A and do what you want.
- Usually, your **containers** and **histograms** will be **attributes of Track, Event or Run**;
 - Therefore you will have to **instantiate TrackingAction** and/or **EventAction** and/or **RunAction**.
 - **Pass their pointer to SteppingAction.**
- This approach is illustrated in:
 - examples/novice N03, N06
 - extended/electromagnetic, optical, and many others ...

- A **G4Step** object consists of **two points**:

```
G4StepPoint* point1 = step->GetPreStepPoint();  
G4StepPoint* point2 = step->GetPostStepPoint();
```

- To get **their positions in the global coordinate system**:

```
G4ThreeVector pos1 = point1->GetPosition();  
G4ThreeVector pos2 = point2->GetPosition();
```

- Hereafter we call “**current volume**” the volume where the step has just gone through.
- Geometrical information is available from **preStepPoint** !

- **G4VTouchable** and its derivatives keep these geometrical information:

```
G4TouchableHandle touch1 = point1->GetTouchableHandle();
```

- To get the **current physical volume**:

```
G4VPhysicalVolume* volume = touch1->GetVolume();
```

- To get its **name**:

```
G4String name = volume->GetName();
```

- To get **copy number**:

```
G4int copyNumber = touch1->GetCopyNumber();
```

- To get **logical volume**:

```
G4LogicalVolume* lVolume = volume->GetLogicalVolume();
```


- To get **material** the following statements are equivalent:

```
G4Material* material = point1->GetMaterial();
```

```
G4Material* material = lVolume->GetMaterial();
```

- To get **region**:

```
G4Region* region = lVolume->GetRegion();
```

- To get **mother volume**:

```
G4VPhysicalVolume* mother = touch1->GetVolume(depth=1);
```

- **grandMother**: depth=2 ...etc...

- To get **copy number of mother**:

```
G4int copyNumber = touch1->GetCopyNumber(depth=1);
```

- **grandMother**: depth=2 ...etc...

- To check that particle has just entered in the current volume, i.e. is at the first step in the volume; the **preStepPoint** is at boundary:

```
if (point1->GetStepStatus() == fGeomBoundary)
```

- To check that particle is leaving the current volume, i.e. is at the last step in the volume; the **postStepPoint** is at boundary:

```
if (point2->GetStepStatus() == fGeomBoundary)
```

- In the above situation, get **touchable of the next volume**:

```
G4TouchableHandle touch2 = point2->GetTouchableHandle();
```

- From **touch2**, all information on the next volume as above.

Get Information About Physics - 1

11

- Physics quantities are available from **step** (`G4Step`) or **track** (`G4Track`).
- To get the **process which has limited the current step**:
`G4VProcess* aProcess = point2->GetProcessDefinedStep();`
- **Current particle name**:
`step->GetTrack()->GetDynamicParticle()->GetDefinition()
->GetParticleName()`
- To get **energy deposition**, **step length**, **displacement** and **time of flight** spent by this step:

```
G4double eDeposit      = step->GetTotalEnergyDeposit();  
G4double sLength      = step->GetStepLength();  
G4ThreeVector displace = step->GetDeltaPosition();  
G4double tof          = step->GetDeltaTime();
```



Geant 4

Get Information About Physics - 2

12

- To get **momentum**, **kinetic energy** and **global time** (time since the beginning of the event) of the track **after the completion of the current step**:

```
G4Track* track          = step->GetTrack() ;  
G4ThreeVector momentum = track->GetMomentum() ;  
G4double kinEnergy     = track->GetKineticEnergy() ;  
G4double globalTime    = track->GetGlobalTime() ;
```

- **Additional remark:** To **transform position** from the global coordinate system to the **local system of current volume**, use **preStepPoint** transformation:

```
G4ThreeVector localPosi = touch1->GetHistory()  
->GetTopTransform().TransformPoint(position) ;
```



Geant 4

And more...

13

- Similarly in **TrackingAction** one can access **track information**:

```
void MyTrackingAction::PostUserTrackingAction(const G4Track* track)
{
    G4double tracklen = track->GetTrackLength();
    G4double charge    = track->GetDefinition()->GetPDGCharge();
    ...
}
```

- See more in:
 - `$G4INSTALL/include/Geant4/G4Step.hh`
 - `$G4INSTALL/include/Geant4/G4Track.hh`
 - ...
- You can retrieve easily quantities at each **step** and **cumulate them** over events or run using user accessors / recorders added to your **EventAction** and **RunAction** classes:

```
G4double dose = aStep->GetTotalEnergyDeposit()/MassTarget;
Run->AddDose(dose);
```



Geant 4

- ✓ What is scoring?

- **Three types of scoring:**

- ✓ User hooks

- **Sensitive Detectors**

- Command-based scoring

What is a Sensitive Detector?

15

- A sensitive detector can be used to simulate the “read-out” of your detector:
 - It is a way to declare a **geometric element “sensitive” to the passage of particles.**
 - It gives the user a handle to **collect quantities** from these elements at **stepping time**
 - For example: energy deposited, position, time information...




Geant 4

Sensitive Detector

16

- A **G4VSensitiveDetector** object can be assigned to **G4LogicalVolume**.
- In case a step takes place in a logical volume that has a **G4VSensitiveDetector** object, this **G4VSensitiveDetector** is invoked **with the current G4Step object**.
 - You can implement **your own sensitive detector classes...**
 - or use **scorer classes** provided by Geant4.



Defining a Sensitive Detector

17

- Basic strategy in **src/DetectorConstruction.cc**

```
G4LogicalVolume* myLogCalor = .....;  
G4VSensitiveDetector* pSensitivePart = new MyDetector("/mydet") ;  
G4SDManager* SDMan = G4SDManager::GetSDMpointer() ;  
SDMan->AddNewDetector(pSensitivePart) ;  
myLogCalor->SetSensitiveDetector(pSensitivePart) ;
```



- Each detector object **must** have a **unique name**:
 - Different **logical volumes** can **share one** detector object.
 - More than one SD object** can be made from the same SD class **with different detector name**.
 - One logical volume cannot have more than one detector objects**. But, one detector object can generate **more than one kinds of hits**.
 - e.g. a double-sided silicon micro-strip detector can generate hits for each side separately.

Sensitive Detector Class

18

- A sensitive detector is a **user-defined** class that you need to derive from **G4VSensitiveDetector**

```
#include "G4VSensitiveDetector.hh"
```

include

```
class G4Step;
```

```
class MyDetector : public G4VSensitiveDetector  
{
```

Base class

```
    public:
```

```
        MyDetector(G4String name);  
        virtual ~MyDetector();
```

SD name in constructor

At each step

```
        virtual G4bool ProcessHits(G4Step*aStep,  
                                    G4TouchableHistory*ROhist);  
};
```

- At **stepping time**, Geant4 kernel checks for you if particle is in the sensitive detector.
 - If so, it gives you the control to **G4VSensitiveDetector::ProcessHits()**
- Do what you want in **ProcessHits()** using **hooks**:
 - See previous section on user hooks to collect information you need from step, track...

Outline


20

- ✓ What is scoring?
- **Three types of scoring:**
 - ✓ User hooks
 - ✓ Sensitive Detectors
 - **Command-based scoring**

- Command-based scoring functionality offers **built-in scoring mesh** and **various scorers** for commonly-used physics quantities such as **dose**, **flux**, etc.
- To use this functionality, access to the **G4ScoringManager** pointer after the instantiation of **G4RunManager** in your **main()**

```
#include "G4ScoringManager.hh"
int main()
{
    G4RunManager* runManager = new G4RunManager;
    G4ScoringManager* scoringManager =
        G4ScoringManager::GetScoringManager();
    ...
}
```

- All of the UI commands of this functionality is in **/score/** directory.
- **/examples/extended/runAndEvent/RE03**



Define a Scoring Mesh

23

- To **define** a scoring mesh, the user has to specify the following:
 - **Shape** and **name** of the 3D scoring mesh.
 - Box, cylindrical mesh
 - **Size** of the scoring mesh. Mesh size must be specified as "half width" similar to the arguments of G4Box.
 - **Number of bins for each axes**. Note that too many bins causes immense memory consumption.
 - Optionally, position and rotation of the mesh. If not specified, the mesh is positioned at the center of the world volume without rotation.

```
# define scoring mesh
/score/create/boxMesh boxMesh_1
/score/mesh/boxSize 100. 100. 100. cm
/score/mesh/nBin 30 30 30
```

- The **mesh geometry** can be **completely independent** from the **real material geometry**.



Geant 4

Scoring Quantities

24

- A **mesh** may have **arbitrary number of scorers**. Each scorer scores **one** physics quantity (xxxxx).
 - **energyDeposit** * **Energy** deposit scorer.
 - **cellCharge** * Cell charge scorer.
 - **cellFlux** * **Cell flux** scorer.
 - **passageCellFlux** * Passage cell flux scorer
 - **doseDeposit** * **Dose deposit** scorer.
 - **nOfStep** * Number of step scorer.
 - **nOfSecondary** * Number of secondary scorer.
 - **trackLength** * Track length scorer.
 - **passageCellCurrent** * Passage cell current scorer.
 - **passageTrackLength** * Passage track length scorer.
 - **flatSurfaceCurrent** * Flat surface current Scorer.
 - **flatSurfaceFlux** * Flat surface flux scorer.
 - **nOfCollision** * Number of collision scorer.
 - **population** * Population scorer.
 - **nOfTrack** * Number of track scorer.
 - **nOfTerminatedTrack** * Number of terminated tracks scorer.

`/score/quantity/xxxxx <scorer_name>`



Geant 4

- Each scorer may take a **filter**:

- charged** * Charged particle filter.

- neutral** * Neutral particle filter.

- kineticEnergy** * Kinetic energy filter.

- ```
/score/filter/kineticEnergy <fname> <eLow> <eHigh> <unit>
```

- particle** \* Particle filter.

- ```
/score/filter/particle <fname> <p1> ... <pn>
```

- particleWithKineticEnergy** * Particle with kinetic energy filter.

- ```
/score/quantity/energyDeposit eDep
```

- ```
/score/quantity/nOfStep nOfStepGamma
```

- ```
/score/filter/particle gammaFilter gamma
```

- ```
/score/quantity/nOfStep nOfStepEMinus
```

- ```
/score/filter/particle eMinusFilter e-
```

- ```
/score/quantity/nOfStep nOfStepEPlus
```

- ```
/score/filter/particle ePlusFilter e+
```

- ```
/score/close
```



Close the mesh when defining scorers is done.

Same primitive scorers with different filters may be defined.

Drawing a Score

26

- **Projection:**

`/score/drawProjection <mesh_name> <scorer_name> <color_map>`

- **Slice:**

`/score/drawColumn <mesh_name> <scorer_name> <plane> <column>
<color_map>`

- **Color map:**

- By default, linear and log-scale color maps are available.
- Minimum and maximum values can be defined by `/score/colorMap/setMinMax` command. Otherwise, min and max values are taken from the current score.

- **Single score:**

`/score/dumpQuantityToFile <mesh_name> <scorer_name> <file_name>`

- **All scores:**


`/score/dumpAllQuantitiesToFile <mesh_name> <file_name>`

- By default, values are written in CSV.
- By creating a concrete class derived from **G4VScoreWriter** base class, the user can define his own file format.
 - Example in **/examples/extended/runAndEvent/RE03**
 - User's score writer class should be registered to G4ScoringManager.

More than One Scoring Mesh

28

- You may define **more than one** scoring mesh.
 - And, you may define **arbitrary number of primitive scorers** to each scoring mesh.
- Mesh volumes **may overlap** with other meshes and/or with mass geometry.
- A **step** is **limited on any boundary**.
- Please be cautious of too many meshes, too granular meshes and/or too many primitive scorers.
 - Memory consumption
 - Computing speed



- Geant4 already equipped for scoring.
- Several methods:
 - Use of user hooks at different stages.
(step, track, event, run,...)
 - Methods for the retrieval of Physics quantities
 - Sensitive detectors & hit collections.
 - Built-in commands for scoring.
 - A rich variety of physics quantities

Thanks for your attention



Geant 4